

Self-Priming Pump

HIGH PRESSURE HOMOGENIZERS AND PLUNGER PUMPS SINCE 1974

Powered by Interpump Group



MODEL
Self-Priming Pump
PS32

MODEL	PRESSURE bar	CAPACITY l/h
Pump	70	
PS32	6.000	

TECHNICAL DATA

Plunger number	3
Stroke (mm)	70
Weight (Kg)	350
Water consumption (l/h)	120
Lubrication oil quantity (kg)	10
Product inlet/outlet connection	Clamp connection 3" / Socket weld flange


Design according to MACHINE DIRECTIVES and the HARMONIZED EUROPEAN STANDARD in force.



Self-Priming Pump

HIGH PRESSURE HOMOGENIZERS AND PLUNGER PUMPS SINCE 1974

Powered by Interpump Group



FEATURES

Liquid End: Forged block made from AISI 316, 3 Plungers made from Integral Ceramic Al₂O₃, H-ECOPUR single element plunger seal
Self-Feeding by gravity

Valve seat and poppet valves made from Stellite 20™

Flow switch alarm on cooling water circuit

Drive Unit:

- Splash lubrication system
- Direct transmission system with gear reducer integrated in the cast iron crankcase
- Nitridized crankshaft

Terminal box

Suitable for CIP/SIP up to 12.000 l/h

Stainless steel frame

MAIN OPTIONS

Electric power board for variable capacity

Abrasive version

Valve design for slurry or formulated products

Digital pressure transmitter, 4-20 mA

***Technical specifications are not mandatory and subject to change without notice.

REV5-02/25-EN



BERTOLI - Brand of INTERPUMP GROUP S.p.A.
Via Giambattista Vico, 2 - 42124 - Reggio Emilia - Italy
Tel. +39 0522 948011 - Fax +39 0522 948080
info@bertoli-homogenizers.com - www.bertoli-homogenizers.com